

## 12 PERIODIC INSPECTION & MAINTENANCE SCHEDULE

In order to have a safe riding, maintain good performance, prolong the motorcycle service life and reduce pollution, make sure to perform the periodic inspection and maintenance.

I: Inspect and clean, lubricate, refill, repair or replace if necessary.

A: Adjust C: Clean R: Replace T: Tighten

Item	Regular Service Mileage (KM)								Notes
	300	1000	3000	5000	7000	9000	11000	13000	
✓ Engine Oil	R	R	R	R	R	R	R	R	Check the oil level every 1000km
✓ Engine Oil Strainer	C		C		C		C		
✓ Gear Oil	R			R	Replace ( R ) at every 5000km.				
Cooling Water									
✓ Spark Plug	Clean ( C ) at every 2000km or replace ( R ) at every 5000km.								
✓ Valve Clearance	Adjust ( A ) at every 4000km.								
✓ Carburetor			I		I		I		
✓ Drive Belt	Inspect ( I ) at every 7000km.								
Drive Chain									
✓ Air Cleaner	Clean ( C ) at every 1000km or replace ( R ) at every 2000km.								
✓ Battery Electrolyte									
✓ Fuel Filter Screen	Replace ( R ) at every 8000km.								
✓ Brake System	I		I		I		I		
Clutch Lever Free Play									
✓ Bolts & Nuts	T	Inspect ( I ) at every 8000km.							
✓ Tire Pressure	I		I		I		I		

The above items are applicable to different models. Perform suitable items for each model. When exceeding the listed mileages, perform maintenance according to the listed intervals. The air cleaner requires more frequent cleaning or replacing when ridden in unusually dusty areas.